



## Rescue Hoist FHTF Check List

### Shut Down

- 1) Remove wire rope and hook from mobile GSE
- 2) Raise and stow hook against hoist bell mouth
- 3) Turn Indicator Switch - off
- 4) Turn 28 VDC power supply - off
- 5) Remove mobile GSE from under the rescue hoist
- 6) Detach connector from hoist
- 7) Detach connectors from control box- if desired
- 8) Detach connector for pendant – if desired
- 9) Lower hanging hoist mount
  - a. Raise chain hoist to unload load cell pins
  - b. Remove load cell pins
  - c. Lower hanging hoist assembly
- 10) Loosen upper then lower mount connectors and boom connector
- 11) Remove hoist