

AxelCut Operating Instructions:

Easy as 1:2:3

1: Grasp the AxelCut by the handle



2: Grab the cable and brace the AxelCut against your body



3: Pull the handle towards you in a fast motion



Installation of Brackets :

Install the supplied mounting brackets as shown in the included installation drawing ZL-1000-10. Mount the bracket with the quick disconnect pin in the top position, as shown in the drawing.

We are now providing you with an optional lanyard: Attach the open end of the lanyard pouch to the ring located on the bottom of the AxelCut. Attach the opposite end of the lanyard pouch through the ring located on the mounting bracket. (see pictures below)



The use of the lanyard is optional.

Important:

If a restraining lanyard is installed, it should be sized to fit the aircraft location and stored in a position that will allow it to spool out freely yet still be long enough to allow the AxelCut to reach the Hoist Cable.

Maintenance:

Pivot Point



Lubricate the AxelCut Blades pivot point with one or two drops of light turbine oil or equivalent on a semi-annual basis. **Important: Do not use solvents on the blades.**

It is recommended to spray the pulleys and handle shaft with a corrosion preventative compound, making sure not to spray on the blades as directed above and wipe clean on semi-annual basis. When using in a salty environment, it is recommended to rinse in fresh water as soon as possible, blow dry by compressed air, and apply clean light oil to the cutting blades and spray the pulleys and handle shaft with a corrosion preventative compound like WD-40 or equivalent.